

What You'll Need

- Spray bottle (water + small drop of dishwashing liquid)
- Clean lint-free cloth or paper towel
- Squeegee (felt edge preferred) or soft cloth
- Masking tape (for positioning larger stickers)
- Pin (for air bubble removal if required)

Before You Start (Critical for Best Results)

- Apply only to clean, smooth, non-porous surfaces
- Ideal temperature: 10°C – 30°C
- Avoid installing in direct sunlight, wind, or dusty areas
- Ensure surface is completely free of dust, grease, wax, or moisture
- Any imperfections will show through the sticker

Pro Tip: Clean with isopropyl alcohol for best adhesion.

Step-by-Step Installation (Wet Application Method)

1. Prepare the Surface	Clean thoroughly and lightly mist with water + detergent mix.
2. Remove Backing	Peel backing carefully without touching adhesive.
3. Position the Sticker	Place onto surface and adjust into position.
4. Apply & Remove Water	Squeegee from centre outward using firm pressure.
5. Final Check	Smooth edges and allow 24 hours for full cure.

Air Bubble Removal

- Small bubbles often disappear within 24–48 hours
- For stubborn bubbles, prick gently with a pin and press air out

Reflective Vinyl (Class 1 & Class 2)

- Flat surfaces only – do **NOT** apply to curves
- Use minimal water if wet applying
- Do **NOT** use heat to conform
- Incorrect application will void warranty

Common Mistakes to Avoid

- Applying to dirty or dusty surfaces
- Using too much water
- Applying in extreme temperatures
- Using sharp or abrasive tools
- Rushing the process

Pro Installation Tips

- Use masking tape hinge method for large decals
- Apply large signs in sections
- Use overlapping squeegee strokes
- Allow 24 hours before washing or exposure

Compliance Reminder

Correct installation ensures visibility, durability, and compliance with Australian Standards (AS1319 / AS1743).

Need Assistance? Contact Us



National Safety Signs

3/140 Millaroo Drive, Helensvale, QLD 4212

Ph: 07 5665 8996